



Kontak Sales : 081388882959 / 081388887599

| NO | SPAREPART                               | SEC.                  | MHE                             |                                           |                                           |                                     |                                |
|----|-----------------------------------------|-----------------------|---------------------------------|-------------------------------------------|-------------------------------------------|-------------------------------------|--------------------------------|
|    |                                         |                       | PALLET<br>MOVER<br>( T-SERIES ) | CB ELECTRIC<br>( E-SERIES )<br>( 3 WHEEL) | CB ELECTRIC<br>( E-SERIES )<br>( 4 WHEEL) | CB<br>DIESEL<br>( H/HT-<br>SERIES ) | REACH<br>TRUCK<br>( R-SERIES ) |
| 1  | SET OF SEAL ASSY.<br>CYLINDER LIFT      | HOIST UNIT ATTACHMENT | MID                             | MID                                       | MID                                       | MID                                 | MID                            |
| 2  | SET OF SEAL ASSY.<br>CYLINDER TILTING   |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 3  | SET OF SEAL ASSY.<br>CYLINDER SIDESHIFT |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 4  | SET OF SEAL ASSY.<br>AXLE CYLINDER      |                       | N/A                             | MID                                       | MID                                       | MID                                 | N/A                            |
| 5  | HOSE PULLEY                             |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 6  | HOSE SIDESHIFT<br>TILTING               |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 7  | HOSE PRESSURE                           |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 8  | HOSE RETURN                             |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 9  | PIPE HYDRAULIC<br>TILTING               |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 10 | PIPE HYDRAULIC<br>SIDESHIFT             |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 14 | MAST BEARING                            |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 11 | MASTER BRAKE<br>CYLINDER                | CONTROL               | N/A                             | MID                                       | MID                                       | MID                                 | FAST                           |
| 12 | BRAKE CYLINDER ( WHEEL )                |                       | N/A                             | MID                                       | MID                                       | MID                                 | FAST                           |
| 13 | BRAKE SHOE                              |                       | N/A                             | MID                                       | MID                                       | MID                                 | FAST                           |
| 14 | JOY STICK SINGLE<br>AXIS                |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 15 | JOY STICK DOUBLE<br>AXIS                |                       | N/A                             | MID                                       | MID                                       | MID                                 | MID                            |
| 16 | STEERING WHEEL                          |                       | N/A                             | SLOW                                      | SLOW                                      | SLOW                                | MID                            |
| 17 | ENCODER                                 |                       | N/A                             | SLOW                                      | SLOW                                      | SLOW                                | MID                            |
| 18 | PARKING BRAKE<br>SWITCH                 |                       | N/A                             | SLOW                                      | SLOW                                      | SLOW                                | FAST                           |
| 19 | POTENTIOMETER<br>ACCELERATION           |                       | N/A                             | FAST                                      | FAST                                      | MID                                 | FAST                           |
| 20 | EMERGENCY PUSH<br>BUTTON                |                       | N/A                             | FAST                                      | FAST                                      | MID                                 | FAST                           |
| 21 | SENSOR PROXIMITY                        | SENSOR                | N/A                             | FAST                                      | FAST                                      | MID                                 | FAST                           |
| 22 | SENSOR STEERING                         |                       | N/A                             | FAST                                      | FAST                                      | MID                                 | FAST                           |
| 23 | LOADWHEEL<br>BEARING                    | WHEEL                 | FAST                            | N/A                                       | N/A                                       | N/A                                 | MID                            |
| 24 | CASTOR WHEEL<br>BEARING                 |                       | FAST                            | N/A                                       | N/A                                       | N/A                                 | MID                            |
| 25 | RELINING<br>LOADWHEEL                   |                       | FAST                            | N/A                                       | N/A                                       | N/A                                 | FAST                           |
| 26 | RELINING<br>DRIVEWHEEL                  |                       | FAST                            | N/A                                       | N/A                                       | N/A                                 | FAST                           |
| 27 | RELINING CASTOR<br>WHEEL                |                       | FAST                            | N/A                                       | N/A                                       | N/A                                 | N/A                            |
| 28 | RELINING STABILIZER<br>WHEEL            |                       | FAST                            | N/A                                       | N/A                                       | N/A                                 | N/A                            |
| 29 | FILTER SUCTION                          | FILTER                | N/A                             | FAST                                      | FAST                                      | MID                                 | FAST                           |
| 30 | BREATHER FILTER                         |                       | N/A                             | FAST                                      | FAST                                      | MID                                 | FAST                           |
| 31 | TRANSMISION FILTER                      |                       | N/A                             | MID                                       | MID                                       | MID                                 | N/A                            |
| 32 | OIL ENGINE FILTER                       |                       | N/A                             | N/A                                       | N/A                                       | FAST                                | N/A                            |
| 33 | FUEL FILTER ENGINE                      |                       | N/A                             | N/A                                       | N/A                                       | FAST                                | N/A                            |